



INCLUDES: Dora Sno-Cone Maker, Ice Shaver, Hand crank, Locking cap, Bottle with cap, Spoon, Palm Tree, Cup Holder, 5 paper cups, I tropical punch flavor packet.

Note to Parents:

- Read instructions thoroughly before use. Adult supervision is suggested with younger children. Not intended for children under 3 years. Handle ice shaver with care.
- Do not wash the Dora the Explorer Sno-Cone Maker in the dishwasher or in hot water.
- Wash all components of the Sno-Cone Maker with warm, soapy water before use.









How to Make Flavoring

- **1.** Combine 1/2 cup of water and 1 envelope of drink mix in a large pitcher. Stir ingredients until flavoring is completely dissolved.
- **2.** Pour flavoring carefully into bottle. Screw bottle top to bottle. Be sure bottle top is tightened securely. DO NOT OVER FILL BOTTLE.

Note: For additional flavoring please see back of Drink Mix package.

How to Make Sno-Cones

- I. Insert paper cup into cup holder.
- **2.** Remove Palm Tree and drop one ice cube into the top of the chute.
- **3**. Begin to turn ice shaver handle clockwise about 5 times without applying pressure. Gently apply pressure to the top of Palm Tree while continuing to turn ice shaver handle.

CAUTION: PUSHING DOWN ON THE PALMTREE PRIOR TO TURNING THE HANDLE MAY RESULT IN JAMMING THE SNO-CONE MAKER.

Continue turning the handle clockwise until the ice cube has been completely shaved.

- 4. Repeat steps 2-3 until you have enough shavings to make a sno-cone.
- **5.** Scoop the ice shavings into the paper cup with Boots' spoon.
- **6.** Squeeze bottle to squirt flavoring over the ice shavings until saturated.

Washing and Cleaning Instructions

To clean your Sno-Cone Maker, rinse with warm (not hot) water and wipe dry. If further cleaning is desired, remove the shaver handle from

the machine. After each use, shake out any water or ice particles left in the machine.



WARNING:

CHOKING HAZARD - Small parts. Not for children under 3 years.



Additional Hints and Suggestions

Additional packets of drink mix flavoring and paper cups can be purchased at your local supermarket or grocery store. Create your own flavors using your favorite fruit juice to make flavored ice cubes. (Ice cube tray not included) Now, place the cubes, one at a time, into the maker and grate. This way you can make flavored snow with or without extra drink mix flavoring.



CAUTION:

This item contains a functional sharp edge on the ice shaver.

©2007 Viacom International Inc. All rights reserved.

Nickelodeon, Nick Jr., Dora the Explorer and all related titles, logos and characters are trademarks of Viacom International Inc.

©2007 Little Kids, Inc., 225 Chapman Street/Suite 202/Providence, RI 02905.

All Rights Reserved. I-800-LIL-KIDS